



AHT Liftgates, LLC

309 Mogie Ln.

Acworth, Ga. 30102

(770) 425-5480

E-Mail: parts@ahtliftgates.com

Web: www.ahtliftgates.com

STEEL TROUBLESHOOTING GUIDE

| PROBLEM | CAUSE | CORRECTION |
|-------------------------------|---|--|
| PLATFORM STOPS WHILE LOWERING | 1) <i>Lift arm pins are seized</i> | - Lubricate all 12 points. Check operator's manual for locations. Most books page 21 |
| | 2) <i>(One) Lift Cylinder Valve wiring is defective. (Only applies to LA Model gates)</i> | Check wire to solenoid on C10 cartridge valves. (valve is on top of lift cylinder) Check both lift cylinders. One of the wires is broken. Replace solenoid. (Only on LA Models with Electrical Hose Burst Valves) |